# Panasonic ideas for life

electronic board UB-5315 UB-5815 UB-5310

**Panaboard**<sup>™</sup>

The Distribution Cycle

Foduct ABC

Microsoft® Windows® 98, Windows® Me, Windows® 2000, Windows® XP operating systems USB 1.1

### Panaboard takes notes instead of you Improves your Presentations and meetings



## **Panaboard Panaboard** Improves your Presentations and Meetings



Seminars Meetings Brain Storming Scheduling Training Copying charts and graphs



### Panaboard UB-5315, UB-5815, UB-5310

- Our range of Panaboards come with an integral printer for easy-operation.
- Plain paper printing with multiple copies. (except UB-5310)
- Panaboard can work as a PC printer.
- Panaboard can be controlled from PC.
- Panaboard keeps 100% audience attention and increases participation.
- Panaboard increases efficiency and reduces meeting time.
- Panaboard can be wall-mounted or used with floor-stand option.
- Panaboard provides multi-copies, logic control and PC interface.


## All-in-one slim design No protruding paper tray.

UB-5315	Endless 2 Screen / Standard size Standard or recycled paper
UB-5815	Endless 2 Screen / Wide size Standard or recycled paper
UB-5310	Endless 2 Screen / Standard size Thermal paper





### Panasonic




### **PC** Interface

#### **Document Management System**

D

Panaboard UB-5315, UB-5815 and UB-5310 comes with utility software that consists of Document Manager and Document Viewer. The meeting contents on the Panaboard screen will become meeting minutes with some annotation by Document Viewer function. The Document Manager makes it easy to file and distribute the meeting minutes quite easily. Supported saving file format is BMP, TIFF, JPG, PNG and PDF.

# The Document Manager makes it easy to file and distribute the meeting minutes quite easily.



The scanned image is monochrome.





#### **TWAIN Driver**

By just one click, you can scan the image on the Panaboard screen as image data to your computer and from your computer, you can control the Panaboard function just like operating the Panaboard control panel.

#### **Printer Driver**

The Panaboard can work as a PC printer. In a meeting, if you need to print out some documents, the Plug & Play of USB makes it easy to print out documents from the Panaboard.



UB-5315 UB-5815 UB-5310

General	Model number	UB-5315	UB-5815	UB-5310		
Power Supply		AC 100 - 120 V, 50/60 Hz or AC 220 - 240 V, 50/60 Hz				
Power Consumption	on (Operational)	1.40 A (AC 100 - 120 V) 0.75 A (AC 220 - 240 V)				
External dimensions (Height X Width X Depth,without stand)		1,334 mm X 1,372 mm X 212 mm	1,334 mm X 1,735 mm X 212 mm	1,440 mm x 1,372 mm x 233 mm		
Weight(without star	nd)	25 kg (55.1 <b>l</b> bs)	27 kg (59.5 lbs)	23 kg (50.7 lbs)		
Ambient operating	conditions	Temperature: 10-35 °C (50-95 °F) Humidity: 30-80% RH				
Writing implements	6	Dry era	ase felt-tipped markers (black, red and	blue)		
Input Block						
Panel dimensions	(Height X Width)	900 mm X 1,262mm	900 mm X 1,625 mm	900 mm X 1,262 mm		
Panel surface		2				
Panel advance sys	stem		Endless scroll type			
Copying area (Hei	ght X Width)	850 mm X 1,250 mm	850 mm X 1,613 mm	850 mm X 1,250mm		
Scanning system			Image sensor			
Output Block						
Printing		Fusion thermal transfer type		Thermal type		
Copy paper		Standard or r	Heat-sensitive roll paper Paper thickness : 65 µm Core diameter : 25.4 mm or more			
Copy paper size		A4/Letter*				
Copy density		8 dots/mm				
Copy color		Black				
Contrast adjustmer	nt	Two levels : Normal/Dark				
2-screen compress	sed copying	Yes				
Time required for C	Copying	15 s/sheet				
Continuous copies		1 to 9				
Paper empty indica	ation		Yes			
Automatic cutter				Yes		
Computer Interfa	acing System Req	uirements				
Computer		IBM <sup>®</sup> PC/AT or compatible machine with a CD-ROM drive				
CPU		Pentium <sup>®</sup> II or higher processor				
Interface		USB 1.1 (B connector)				
OS		Windows <sup>®</sup> 98/Me/2000/XP				
Memory		64 MB or more (Windows <sup>®</sup> 98/Me) 128 MB or more (Windows <sup>®</sup> 2000) 256 MB or more (Windows <sup>®</sup> XP)				
HD		At least 40 MB free space (except saving space for image file)				

Accessories

- Eraser Software CD-ROM Operating instructions, Installation manual • Markers (Black, Red, Blue) •Thermal transfer film (for UB-5315, UB-5815)
- Wall-mount kit (Upper, Lower)
- •Thermal paper roll (for UB-5310)

Se	parate	elv Δ	vaila	able
36	parat		vanc	aDIC

Stand : UE-608005	
Replacement film : UG-6001 (Set of 2 rolls [50m] for UB-5315, UB-5815)	
Markers : KX-B031 (set of 10 black markers), KX-B032 (set of 10 red markers),	
KX-B033 (set of 10 blue markers)	
Erasers : KX-B042 (set of 6 erasers)	
Marker and eraser set : KX-B035 (contains 1 black, 1 red, and 1 blue markers and 1 eraser)	

\* Letter size is for U.S.A. and Canada models.

- Note: Microsoft and Windows are either registered trademarks or trademarks

- Microsoft and windows are either registered trademarks of rademarks of discrosoft Corporation in the United States and/or other countries.
  Windows® is Microsoft® Windows® operating system.
  IBM is a registered trademark of International Business Machines Corporation.
  Pentium is a registered trademark of Intel Corporation in the U.S. and other countries.
  All trademarks referred to in this catalog are property of their respective companies.

### http://panasonic.co.jp/pcc/en/ http://www.panasonic.co.jp/global

Design and specifications are subject to change without notice. PCC0803I/EU-5315ULC-02 Printed in Japan

